

Live Edge Australian Burls



Step !... plane flat face smooth... requires large planer (12"), sand to final finish



Step 2... run through re-saw bandsaw to make a flat spot on bottom using sled from step 6

Step 3... run through thickness planer to ensure top and bottom are smooth and parallel



Step 4... glue a sacrificial block to center of bottom to attach a faceplate



Step 5... mount on lathe, core inside for second bowl, finish turn inside and sand and final finish top as desired



Step 6... cut off sacrificial block using bandsaw



Step 7... Run through planer or drum sander to smooth off bottom, finish as desired



Finished product



Second bowl from core

